

JURA 3-phase cleaning tablets

Tablets for cleaning and protecting JURA fully automatic coffee machines

UFI: AD70-Q04A-300P-Q9TM

Mode of action

Alkaline cleaning tablets especially developed for JURA fully automatic coffee machines for thorough removal of coffee fat and deposits. The formulation is tailored to use in JURA fully automatic coffee machines and ensures effective while gentle cleaning, thereby extending the life of your coffee machine. They can also be used for thermos flasks and other containers/devices where deposits must be removed. Please see that the tablets must be dissolved with water of at least 90 °C.

Properties

Tablet, cylindrical, convex bottom, hemispheric top
Colour: white bottom/mid dark blue/blue top
Neutral odour
Height: < 15.2 mm
Diameter: 16.1 mm ± 0.1 mm
Weight: 3.4 g ± 0.1 g
Soluble in water.
Dissolving time (0.25 l/90 °C): < 10 min

Ingredients

(according to regulation (EC) No 648/2004)
SODIUM CARBONATE
SODIUM CITRATE
SODIUM GLUCEPTATE
SODIUM CARBONATE PEROXIDE
SODIUM SULFATE
ADIPIIC ACID
SODIUM C14-16 OLEFIN SULFONATE
MAGNESIUM STEARATE
SODIUM LAURYL SULFATE
COLORANT

For more information on the ingredients please click [here](#).

Instructions for use

1. Place a sufficiently large receptacle (ca. 0.5 litres) under the height-adjustable coffee spout.
2. Start the cleaning operation as described in the instructions for use of your machine.
3. Drop a cleaning tablet inside the filler funnel for pre-ground coffee.
4. The rest of the procedure is described in the instructions for use of your machine.

Packing units

Folding box of 2 tablets in a blister, folding box of 6 tablets in a blister, jar of 25 tablets, jar of 100 tablets
Art. No. 59633, 68009, 58710, 24224, 24226, 24225, 25045, 25053

Toxicological and ecological information

The product is classified as irritant, i. e., short, frequently or prolonged contact with skin may cause inflammations. The product complies with the biodegradability criteria as laid down in Regulation (EC) No. 648/2004 on detergents.

Handling, storage and disposal considerations

Keep container tightly closed, protect against humidity, water and heat.
Waste code product: 20 01 29

Hazards identification

Warning

H315: Causes skin irritation.

H319: Causes serious eye irritation.

P101: If medical advice is needed, have product container or label at hand.

P102: Keep out of reach of children.

P264: Wash hands thoroughly after handling.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P332+P313: If skin irritation occurs: Get medical advice/attention.

P337+P313: If eye irritation persists: Get medical advice/attention.

First aid measures

In case of accident or if you feel unwell, seek medical advice immediately (show directions for use or safety data sheet if possible).

General information: No special measures required.

After inhalation: Supply fresh air.

After skin contact: Immediately rinse with water.

After eye contact: Rinse opened eye for several minutes under running water. Then consult a doctor.

After swallowing:

Rinse out mouth and then drink plenty of water.

Do not induce vomiting.

If symptoms persist, consult a doctor.

JURA Elektroapparate AG
Kaffeeweltstrasse 10
CH-4626 Niederbuchsiten
Tel.: +41 (0) 62 389 82 33
[jura.com](#)

JURA Elektrogeräte Vertriebs-GmbH
Postfach 99 01 44
D-90268 Nürnberg
Tel.: 0180 3 523 333
[de.jura.com](#)

JURA Gastro Vertriebs-GmbH
An der Zugspitze 1
D-82491 Grainau
Tel.: +49 (0) 8821 966 73-0
[juragastroworld.de](#)